



GIRO
Series




POP
Series




SKIPPER
Series




SKIPPER
Pocket 4C



230V 50 Hz



230V 50 Hz



ON POWER

N - Blue - Neutral

L1 - Brown - Phase

L2 - White - Wired switch
(optional)

PE - Yellow / Green - Earth

ON DEVICE

N - Blue - Neutral

M1 - Brown - Phase

PE - Yellow / Green - Earth